

SPAX ENGINEERED FASTENERS



PROJECT GUIDE

**DRIVING LASTING BEAUTY
INTO KITCHEN & BATH**

KITCHEN AND BATH PROJECT GUIDE

A home's kitchen and bathroom serve dramatically different purposes, but both spaces share the same goal—pairing functionality with serenity. SPAX® Engineered Fasteners help you create strong connections for virtually every part of your kitchen and bathroom remodels. Use this guide to find the right products for your connections and get tips from the SPAX Crew to amplify your results.

Multi-Purpose

T-STAR plus, Partial Thread FLAT HEAD				T-STAR plus, Partial Thread WAFER HEAD	
#8	#9	#10	#14	#8	#10
1-1/4"	2-1/2"	1-1/2"	3"	3-1/2"	1-1/4"
1-1/2"	3-1/4"	2"	3-1/2"	4"	1-1/2"
2"		2-1/2"	4-3/4"	2"	3"
2-1/2"				2-1/2"	

T-STAR plus, Partial Thread FLAT HEAD, HCR-X™				T-STAR plus, Partial Thread WAFER HEAD, HCR-X™			
#8	#9	#10	#14	#8	#10		
1-1/4"	2"	2-1/2"	1-1/2"	3"	1"	2"	3-1/2"
1-1/2"	2-1/2"	3-1/4"	2"	3-1/2"	1-1/4"	2-1/2"	4"
			2-1/2"	3-1/2"	1-1/2"	3"	4-3/4"
			1-1/2"	3"	2"		

Special Purpose

T-STAR plus, Partial Thread MDF/HARDWOOD TRIM HEAD		Cross Recess, Partial Thread WAFER HEAD
#6	#8	#8
1-1/2"	1-3/4"	1-1/4"
	2-1/2"	

PowerTrim™

T-STAR plus, Partial Thread TRIM HEAD, HCR®				T-STAR plus, Double Thread TRIM HEAD, HCR®			
WHITE HCR®		YELLOW HCR®		WHITE HCR®		YELLOW HCR®	
#8	#8	#9		#8	#8		
2"	1-1/4"	2"	3-1/8"	4"	2"	2"	3-1/8"
2-1/2"	1-1/2"	2-1/2"		5"	2-1/2"	2-1/2"	

DRIVE CONFIDENCE INTO EVERY CONNECTION

MDF Hardwood
#8 x 2-1/2" MDF engineered fasteners deliver a clean, flush finish for cabinetry.

Multi-Purpose (HCR-X)
Mitigate moisture issues in ventilation installation with HCR-X Multi-Purpose fasteners.

Multi-Purpose
Choose high-strength, low-profile #10 x 3" Wafer Head fasteners for hanging cabinets.

PowerTrim™
Virtually disappears in wood and PVC—the perfect choice for finish carpentry.

Multi-Purpose
Multi-Purpose engineered fasteners ensures subfloor installation with long-term reliability.

- 40% LESS TORQUE NEEDED
- + ZERO PRE-DRILLING
- + REDUCED STRIPPING
- = HOURS SAVED



Multi-Purpose

Special Purpose

PowerTrim™

PRO TIPS FROM THE #SPAXCREW



CONNECTING AND SECURING CABINETRY FROM KEN HARRIS @KH_WOODWORKING



TIP #1 Always start from the high point on the floor (you can find with a laser level).

TIP #2 Invest in the Pony-Jorgensen cabinet claws, or something similar—they allow you to pull two cabinet faces together and flush the faces together, all at the same time. Use T-STAR plus MDF/Hardwood screws to fasten them together.

TIP #3 Use T-STAR plus Wafer Head Cabinet Screws to secure the rear panels to the wall.



KITCHEN AND BATHROOM REMODELING TIPS FROM OSCAR LOZA @KNOTTYDOGWOODSHOP



TIP #1 Avoid hitting electrical or plumbing lines by choosing the right length for your fasteners.

TIP #2 Don't be afraid to use shims. If you need a bunch of shims, it's not your install work, it's the walls. Plus, they get covered anyways.

For more pro tips,
follow us on Instagram
@SPAX_US

LEARN MORE AT [SPAX.US/PRO-DESK](https://www.spax.us/pro-desk)



ALTENLOH, BRINCK & CO. US, INC.
2105 County Road 12C
Bryan, OH 43506